

## **Care and Cleaning Instructions**

### **Routine Care**

Essential Wash-Planes high strength acrylic product is very easy to clean: after each use, simply wipe with a soft cloth to remove any surface dirt.

For standard cleaning, we recommend using widely available cleaning products, such as *"Spray & Wipe"*, *"Sugar Soap"* etc.

Never using petroleum-based products when cleaning, i.e. Paint thinners, Turpentine or other solvents, as they may damage the solid surface.

(Note: Personal hygiene products and cosmetics will NOT damage the surface.)

### **Standard Cleaning**

Wiping surface with a soft cloth after each use.

Always use mild cleaning products, such as *"Spray & Wipe"*, *"Sugar Soap"* etc.

For more difficult stains, using a mildly abrasive cream cleanser, such as *"Jif"*

### **About This Cleaning Advice**

This information is offered as a general guide only. This guidance does not preclude the use of other methods, materials or equipment; however the user should undertake careful evaluation and make suitable enquiries as to the suitability of alternative methods, materials or equipment, before using them.

All reasonable care has been taken in producing this document, however Essential Wash-Planes makes no representations or warranties, express or implied, as to the accuracy, reliability or completeness of, and disclaims all liability, direct or indirect and whether or not arising out of the negligence, default or lack of care of Essential Wash-Planes high strength acrylic product for any loss or damage (whether foreseeable or not) suffered by the recipient or any other person arising out of, or in connection with, any use of reliance by any of them on this document. Liability which cannot legally be excluded is limited to the maximum extent possible.