


If the wash-plane is too long and too heavy, we suggest installing stronger support brackets underneath, to ensure it's strong enough and no distortion of the solid surface wash-plane occurs over time.



All measurements are subject to accepted manufacturing tolerances.

To ensure accuracy please check actual product dimensions before drilling for installation.

The manufacturer reserves the right to change specifications at any time without giving prior notification.

This product should be installed by a qualified plumber. Local authority, Water Board, and Building Regulations may apply to the installation of this product, and you should consult the appropriate bodies on these requirements.

## IMPORTANT



Provide suitable reinforcement behind finished wall for the solid surface wash-plane. Fixing at the fixing height position.

### Roughing in for solid surface basin Fixing Kit:


For timber stud walls, noggin's and studs must be positioned at a height to allow for the location of fasteners.

### BASIN INSTALLATION FOR REFERENCE:

- 1- Confirm the Fixing Height position of wash-plane on finished wall.
- 2- Have a horizontal(level) line, take measurement and mark fixing screw hole position on finished wall at confirmed height.
- 3- Drill  $\text{\O}12\text{mm}$  wall hung holes in masonry wall for expansion fasteners. For timber stud walls drill two  $\text{\O}8\text{mm}$  holes for Fixing Screws (supplied).
- 4- Insert expansion fasteners into the drilled holes in masonry wall. Screw Fixing Screws into the wall using the flats located on the screws section of the stud and spanner as shown in **Figure 1** and **Figure 2**.  
Allow 40mm of thread to protrude from the finished wall.
- 5- Fit taps (if applicable) and waste assembly to the wash-plane .
- 6 - Locate wash-plane onto the Fixing Screws on the wall. Insert plastic bushes, metal washers and fasten to wall with fixing nut. To complete assembly as shown in **Figure 3**.
- 7- Tighten fixing nuts and connect plumbing to complete the installation.



### Fixing Screw Masonry Walls Installation



### Fixing Screw Timber Stud Walls Installation




Figure 3.

Figure